

TS-112-B27HD HEAVY DUTY LOAD MODULE SYSTEM

Technical specification:

<u>Type</u>	TS-112-B27H
<u>Capacity</u>	112,000 lbs.
<u>Composition</u>	- 4 aluminium extrusion supporting plates with air caster element B27HD - 5 hoses with camlock couplings - 1 air regulator manifold with (4) outlet valves - 1 User Manual
<u>Air casters</u>	B27HD, with a max. capacity of 28,000 lbs at 60 psi. The air consumption is approx. 35-67 cfm each, depending on the adjustment, the load and the quality of the floor.
<u>Dimensions</u>	The air caster load module is a slide mounted load module and consists of a solid aluminium plate, 5/8in thick and an air caster B27HD with landing pads. Dimensions 27 x 27 x 1 3/16 in. in with integrated air through let.
<u>Air regulation</u>	The air regulation is composed of a steel box on castors with two handles and dimensions L x W x H = ca. 18 x 14 x 8". The important parts of this unit are: <ol style="list-style-type: none">1. safety connections for the air supply to the air regulation unit2. ball valve as main valve in the main air supply3. pressure gauge to indicate supply pressure4. regulator to adjust the pressure in each air caster5. pressure gauge to indicate pressure in each air caster6. safety couplings for the air supply to each air caster7. the air regulation unit is finished in safety yellow (RAL 1018).
<u>Hoses</u>	1 main air supply hose 1" of 33ft with safety quick connect couplings. <i>other lengths on request for an additional price</i> 2 hoses 3/4" of 10ft with safety couplings. 2 hoses 3/4" of 16ft with safety couplings.
<u>The lift</u>	The lift is approx. 2in depending on the adjustment, the load and the floor.
<u>Operation</u>	The operation of the air casters is being done with the on / off ball valve and the pressure regulators on the regulation unit. For an extensive instruction to operate we refer to the manual.
<u>Manual</u>	We can supply you with a manual in different languages.
<u>Floor</u>	The floor is an important part of the air caster transport system. In order to create sufficient air film and a minimal air consumption the floor must be of a sufficient quality. See for more information our brochure: "Air caster transport and the floor".

technical changes reserved